

مسحوق طلاء ب عدم وجود قضبان يدوية للون للدرج في الخارج أو داخلي استعمال وبعديتم توفير جميع الأقواس / البراكن اللازمة

مستاء للقضبان اليدين الصلب

- درج درابزين الأوسط السكك الحديدية لنشر قوس



- 32 * 32 □□□□□□ □□□□□□ □□□



40 * 40 □□□ □□□□□□ □□□mm-



□□□□ □□□□□□ □□□□ □□□



□□□□□□ □□□-





□□□□□□ □□□□

Guard Rail Assembly Instructions

Tools Required: Electrical Power Drill
(Impact Drill Preferred)

Overview: Assemble the rail and position it before marking holes for drilling. Improper installation can lead to failure of rail system or injury.

1 Roughly position the 2 posts.

2 Put the post base caps on without securing them.

3 Secure top rail & post with brackets - 4 screws each.

4 Add the ends to the top rail.

5 Secure inside rail with brackets - 2 screws each.¹

6 Position whole rail. Mark the 4 holes on each post.

¹ Inside rail will be loose until each post is secured to the ground.

7 Remove hand rail, drill holes straight down, and hammer in bolts.²

8 Put hand rail over bolts, tighten nuts onto bolts.

² Double check posts are parallel and tight against inside rail before marking holes for drilling.

9 Insert the vertical railings.

10 Secure all of the inner rail.³

³ Push and pull top rail & inside rail to ensure all is secure.









