


Shenzhen Launch fabrica sistema de trilhos de proteção de aço zinco externo fácil de instalar. Oferecemos conjuntos completos de acessórios para os clientes fazerem a instalação facilmente.

Características do sistema de trilhos de proteção de aço zinco externo -

| | |
|----------|-----------------------------------------------------------------------------------------------------------------------|
| Material | Aço galvanizado ou alumínio |
| Terminar | revestimento em pó de cor preta |
| Tamanho | Corrimão superior 80 * 40mm; Poste de 40 * 40 mm, trilhos verticais de 12 * 12 mm, trilho intermediário de 32 * 32 mm |
| Montagem | DIY fácil |
| MOQ | 1 metro |

Sistema de trilhos de proteção de aço zinco externo, conjunto de amostra -







Instruções de montagem do sistema de trilhos de proteção de aço zinco externo -

Guard Rail Assembly Instructions

Tools Required: Electrical Power Drill
(Impact Drill Preferred)


Overview: Assemble the rail and position it before marking holes for drilling. Improper installation can lead to failure of rail system or injury.

-
- 1 Roughly position the 2 posts.
 - 2 Put the post base caps on without securing them.
 - 3 Secure top rail & post with brackets - 4 screws each.
 - 4 Add the ends to the top rail.
 - 5 Secure inside rail with brackets - 2 screws each.¹
 - 6 Position whole rail. Mark the 4 holes on each post.
 - 7 Remove hand rail, drill holes straight down, and hammer in bolts.²
 - 8 Put hand rail over bolts, tighten nuts onto bolts.
 - 9 Insert the vertical railings.
 - 10 Secure all of the inner rail.³
- ¹ Inside rail will be loose until each post is secured to the ground.
- ² Double check posts are parallel and tight against inside rail before marking holes for drilling.
- ³ Push and pull top rail & inside rail to ensure all is secure.

Fotos de produção do sistema de trilhos de proteção de aço zinco externo-














Galerias do Guard Rail -





www.chinabalustrade.com

